







Here are some handy care instructions to help you get the most out of your scooter.



DO

- Purchase a cover if you intend to use during rainfall.
- Store your scooter somewhere dry, either indoors, garage or shed.
- Turn the power off when transferring to and from the scooter.
- Ensure the seat is in a fixed position facing forwards before driving.
- Ensure the batteries are fully charged before your journey.
- Avoid rough or soft terrain and long grass wherever possible.
- Turn the power off when not in use.
- Remember to read the manufacturers instructions.



DON'T

- Leave your scooter outside in the rain or use during rainfall without a cover.
- Exit or enter the scooter unless the power is switched off.
- Switch off the power whilst driving this will cause the scooter to stop abruptly.
- Exceed the stated weight limit.
- Travel through water or over soft terrain (mud, sand etc.)
- Turn sharply at full speed.
- Leave on charge for more than 12 hours .